

P/N: PMKG-IMP-CLP

IMPACT POLE MOUNTING KIT

Installation Instructions:

The kit consists of the following components:

Strut Rails - QTY (2)



Pipe Clamps - QTY (4)



Fender Washer 1/4"
QTY (4)



Nylok Nut. 1/4-20
QTY (4)



Square Nuts 5/16-18
QTY (2)



Pan Head Screws 1/4-20 x 3/4" Long
QTY (4)



Hex Cap Screws 5/16-18 x 1- 1/4" Long
QTY (2)



1. Place Strut Rails over mounting flange holes on the back of enclosure and insert clamp halves.

(A)



(B)



2. Insert Pan Head Screw through mounting flange hole into Strut Rail. Place the Fender Washer and Nylok Nut on the inside of the rail and secure. **Note: Torque to 32 in-lbs Max.**

(A)



(B)



3. Place Pipe Clamps around pole in desired position and secure with Square Nut and Hex Cap Screw. **Note: Torque to 100 in-lbs Max.**

(A)



(B)

