

UPMK UNIVERSAL POLE MOUNTING KITS

Installation Instructions:

The kit consists of the following components:

Strut Rails - QTY (2)



Nylok Nut. 1/4-20
QTY (8)



Fender Washer 1/4"
QTY (12)



Small Hose Clamp
QTY (2)



Medium Hose Clamp
QTY (2)



Hose Clamp Bracket - QTY (2)



Spacer 1/4" x 1/4", Black
QTY (4)



Large Hose Clamp
QTY (2)



Pan Head Screws
1/4-20 x 1/2" Long - QTY (8)



Pan Head Screws
1/4-20 x 7/8" Long - QTY (4)



Integra Enclosures, Ltd.

8989 Tyler Blvd | Mentor, OH 44060 | Phone: 440-269-4966 | Fax: 440-269-4977 | www.integraenclosures.com | INSTALL-SHT-UPMK_REV_B

*Pick Hose Clamp based on pole size

Mounting Bosses Installation:

1. Attach the Hose Clamp Bracket to the inside of the Strut Rail. Use the 1/2" Pan Head Screw, Fender Washer, and Nylok Nut to secure.

Note: Torque to 32 in-lbs Max.



2. Attach rails to enclosure by placing washer over mounting bosses and secure with 1/2" Pan Head Screw.

Note: Torque to 32 in-lbs Max.



3. Feed Hose Clamp through slots of the Bracket. Wrap Hose Clamp around pole and tighten.

(A)



(B)



Mounting Flange Installation:

1. Attach the Hose Clamp Bracket to the inside of the Strut Rail. Use the 1/2" Pan Head Screw, Fender Washer, and Nylok Nut to secure.

Note: Torque to 32 in-lbs Max.



2. Insert 7/8" Pan Head Screw through mounting flange hole. Align with Fender Washer and Spacer on opposite side. Attach Strut Rail using Fender Washer and Nylok Nut to secure. Note: Torque to 32 in-lbs Max.

(A)



(B)



3. Feed Hose Clamp through slots of the Bracket. Wrap Hose Clamp around pole and tighten.

(A)



(B)

